


NOTE@ USER GUIDE

Getting started

Thank you for choosing Infinix smartphone. We hope this product will bring you a brand new experience.

Features



Note: Only use compatible charger; immovable inbuilt battery. The phone can be restarted by holding the power button for 10 seconds.

i

Inserting SIM card

1. Switch off the mobile phone and remove the rear cover.
2. Insert the SIM card in the card slot properly.
3. Finally, replace the rear cover of the mobile phone.



Inserting memory card

1. Switch off the mobile phone and remove the rear cover.
2. Insert the Micro SD card into the slot.
3. Finally, replace the rear cover of the mobile phone.

Note: Use only compatible memory cards with the device. Incompatible memory cards may damage the card or the device and corrupt the data stored in the card.

ii

Charging the phone


You can charge your device using a charger or by connecting it to the computer using a USB cable (comes with the phone).

Note: Only use compatible charger; immovable inbuilt battery. The phone can be restarted by holding the power button for 10 seconds.



Making a call


On the Home Screen, tap and dial a complete phone number to make a call.



iii

Call log


In the call log, you can make a call, add new contact or send a message.



Tap the icon to dial.

Sending and receiving message(s)

Enter Messaging, and then compose new message. You can open the keyboard by tapping on a text field.



iv

a. When you are composing a new text message, you can select text for cutting or copying. The selected text is highlighted in blue. Tap and hold the text field or portion that contains text. You can select all texts, copy, cut and paste.

When a new message is received, you can read it by opening the notification panel and clicking the message, or entering Messaging to read it directly.